ARM ARCHITECTURE

ARM history



- 1983 developed by Acorn computers
  - To replace 6502 in BBC computers
  - 4-man VLSI design team
  - Its simplicity comes from the inexperience team
  - Match the needs for generalized SoC for reasonable power, performance and die size
  - The first commercial RISC implemenation
- 1990 ARM (Advanced RISC Machine), owned by Acorn, Apple and VLSI

ARM Ltd



Design and license ARM core design but not fabricate

Why ARM?



- One of the most licensed and thus widespread processor cores in the world
  - Used in PDA, cell phones, multimedia players, handheld game console, digital TV and cameras
  - ARM7: GBA, iPod
  - ARM9: NDS, PSP, Sony Ericsson, BenQ
  - ARM11: Apple iPhone, Nokia N93, N800
  - 90% of 32-bit embedded RISC processors till 2009
- Used especially in portable devices due to its low power consumption and reasonable performance

ARM powered products

Popular ARM architectures



- ARM7TDMI
  - 3 pipeline stages (fetch/decode/execute)
  - High code density/low power consumption
  - One of the most used ARM-version (for low-end systems)
  - All ARM cores after ARM7TDMI include TDMI even if they do not include TDMI in their labels
- ARM9TDMI
  - Compatible with ARM7
  - 5 stages (fetch/decode/execute/memory/write)
  - Separate instruction and data cache
- ARM11

ARM family comparison



ARM family attribute comparison.

year	1995	1997	1999	2003
	ARM7	ARM9	ARM10	ARM11
Pipeline depth	three-stage	five-stage	six-stage	eight-stage
Typical MHz	80	150	260	335
mW/MHz[a]	0.06 mW/MHz	0.19 mW/MHz (+ cache)	0.5 mW/MHz (+ cache)	0.4 mW/MHz (+ cache)
MIPS[b]/MHz	0.97	1.1	1.3	1.2
Architecture	Von Neumann	Harvard	Harvard	Harvard
Multiplier	8 × 32	8 × 32	16 × 32	16 × 32

[a] Watts/MHz on the same 0.13 micron process.
[b] MIPS are Dhrystone VAX MIPS.

ARM is a RISC



- RISC: simple but powerful instructions that execute within a single cycle at high clock speed.
- Four major design rules:
  - Instructions: reduced set/single cycle/fixed length
  - Pipeline: decode in one stage/no need for microcode
  - Registers: a large set of general-purpose registers
  - Load/store architecture: data processing instructions apply to registers only; load/store to transfer data from memory
- Results in simple design and fast clock rate
- The distinction blurs because CISC implements RISC concepts

ARM features



- Different from pure RISC in several ways:
  - Variable cycle execution for certain instructions: multiple-register load/store (faster/higher code density)
  - Inline barrel shifter leading to more complex instructions: improves performance and code density
  - Thumb 16-bit instruction set: 30% code density improvement
  - Conditional execution: improve performance and code density by reducing branch
  - Enhanced instructions: DSP instructions

ARM architecture



ARM architecture

- Load/store architecture
- A large array of uniform registers
- Fixed-length 32-bit instructions
- 3-address instructions



Registers



- Only 16 registers are visible to a specific mode. A mode could access
  - A particular set of r0-r12
  - r13 (sp, stack pointer)
  - r14 (lr, link register)
  - r15 (pc, program counter)
  - Current program status register (cpsr)
  - The uses of r0-r13 are orthogonal

General-purpose registers





- 6 data types (signed/unsigned)
- All ARM operations are 32-bit. Shorter data types are only supported by data transfer operations.

Program counter



- Store the address of the instruction to be executed
- All instructions are 32-bit wide and word-aligned
- Thus, the last two bits of pc are undefined.

Program status register (CPSR)





Processor modes



Processor mode		Description
User	usr	Normal program execution mode
FIQ	fiq	Supports a high-speed data transfer or channel process
IRQ	irq	Used for general-purpose interrupt handling
Supervisor	svc	A protected mode for the operating system
Abort	abt	Implements virtual memory and/or memory protection
Undefined	und	Supports software emulation of hardware coprocessors
System	sys	Runs privileged operating system tasks

Register organization