



# RULES OF ELECTRICAL WIRING



- The total lighting load in a sub circuit should not be more than 100W.
- Every fitting or appliance must be controlled by switch.
- Every socket outlet must be controlled by switch.
- The switch should be on the line conductor.
- The incandescent lamp should be hanged at least 2.5 m above the floor level.
- All the metal coverings, frames etc. should be earthed.
- Every sub circuit must have a separated distribution fuse.