

## 2.18 Rotary compressors:

Rotary compressors have a rotor to develop pressure. They are classified as

(1) Positive displacement compressors and (2) Non positive displacement (Dynamic) compressors

In positive displacement compressors, the air is trapped in between two sets of engaging surfaces. The pressure rise is obtained by the back flow of air (as in the case of Roots blower) or both by squeezing action and back flow of air (as in the case of vane blower). Example: (1) Roots blower, (2) Vane blower, (3) Screw compressor.

In dynamic compressors, there is a continuous steady flow of air. The air is not positively contained within certain boundaries. Energy is transferred from the rotor of the compressor to the air. The pressure rise is primarily due to dynamic effects.

Example: (1) Centrifugal compressor, (2) Axial flow compressor.

### 2.18.1 Roots blower:

The Roots blower is a development of the gear pump.

**Construction:** It consists of two lobed rotors placed in separate parallel axis of a casing as shown in fig:4.11. The two rotors are driven by a pair of gears (which are driven by the prime mover) and they revolve in opposite directions. The rotor are of cycloid shape to ensure correct mating. A small clearance is maintained between the rotor and casing. This reduces the wear of moving parts.




Fig: 2.11 Roots blower

**Working:** When the rotor is driven by the gear, air is trapped between the lobes and the casing. The trapped air moves along the casing and discharged into the receiver. There is no increase in pressure since the flow area from entry to exit remains constant. But, when the outlet is opened, there is a

back flow of high pressure air in the receiver. This creates the rise in pressure of the air delivered. These types of blowers are used in automobiles for supercharging.

### 2.18.2 Vane blower:

**Construction:** A vane blower consists of (1) a rotor, (2) vanes mounted on the rotor, (3) inlet and outlet ports and (4) casing. The rotor is placed eccentrically in the outer casing. Concentric vanes (usually 6 to 8 nos.) are mounted on the rotor. The vanes are made of fiber or carbon. Inlet suction area is greater than outlet

delivery area.




Fig: 2.12 Vane blower

**Working:** When the rotor is rotated by the prime mover, air is entrapped between two consecutive vanes. This air is gradually compressed due to decreasing volume between the rotor and the outer casing. This air is delivered to the receiver. This partly compressed air is further increased in pressure due to the back flow of high pressure air from the receiver.

**Advantages:** 1. Very simple and compact, 2. High efficiency 3. Higher speeds are possible

### 2.18.3 Centrifugal compressor

**Construction:** It consists of an impeller, a casing and a diffuser. The impeller consists of a number of blades or vanes, is mounted on the compressor shaft inside the casing. The impeller is surrounded by the casing.




Fig: 2.13 Centrifugal compressor




Fig: 2.14 Pressure – velocity Plot

**Working:** In this compressor air enters axially and leaves radially. When the impeller rotates, air enters axially through the eye of the impeller with a low velocity. This air moves over the impeller vanes. Then, it flows radially outwards from the impeller. The velocity and pressure increases in the impeller. The air then enters the diverging passage known as diffuser. In the diffuser, kinetic energy is converted into pressure energy and the pressure of the air further increases. It is shown in fig:4.14. Finally, high pressure air is delivered to the receiver. Generally half of the total pressure rise takes place in the impeller and the other half in the diffuser.

**Applications:** Centrifugal compressors are used for low pressure units such as for refrigeration, supercharging of internal combustion engines, etc.

### 2.18.4 Axial flow compressor

In this air compressor, air enters and leaves axially.

**Construction:** It consists of two sets of blades: Rotor blades and stator blades. The blades are so arranged that the unit consists of adjacent rows of rotor blades and stator blades as shown in fig:4.15. The stator blades are fixed to the casing. The rotor blades are fixed on the rotating drum. The drum is rotated by a prime mover through a driving shaft. Single stage compressor consists of a row of rotor blades followed by a row of stator blades. Compression of air takes place in each pair of blades (one rotor blade and one stator blade). Hence there are many stages of compression in this type of compressor.

**Working:** When the switch is switched on, the prime mover rotates the drum. Air enters through the compressor inlet and passes through the rotor and stator blades. While passing through the blades, the air is compressed between the blades. The air is also compressed between the casing and the blades. The air