



Case study: RISC and CISC Architecture

Reduced Instruction Set Architecture (RISC) –

The main idea behind this is to make hardware simpler by using an instruction set composed of a few basic steps for loading, evaluating, and storing operations just like a load command will load data, a store command will store the data.

Complex Instruction Set Architecture (CISC) –

The main idea is that a single instruction will do all loading, evaluating, and storing operations just like a multiplication command will do stuff like loading data, evaluating, and storing it, hence it's complex.

Both approaches try to increase the CPU performance

- **RISC:** Reduce the cycles per instruction at the cost of the number of instructions per program.
- **CISC:** The CISC approach attempts to minimize the number of instructions per program but at the cost of an increase in the number of cycles per instruction.

$$CPU\ Time = \frac{Seconds}{Program} = \frac{Instructions}{Program} \times \frac{Cycles}{Instructions} \times \frac{Seconds}{Cycle}$$

Earlier when programming was done using assembly language, a need was felt to make instruction do more tasks because programming in assembly was tedious and error-prone due to which CISC architecture evolved but with the uprise of high-level language dependency on assembly reduced RISC architecture prevailed.

Characteristic of RISC –

1. Simpler instruction, hence simple instruction decoding.
2. Instruction comes undersize of one word.
3. Instruction takes a single clock cycle to get executed.
4. More general-purpose registers.
5. Simple Addressing Modes.
6. Fewer Data types.
7. A pipeline can be achieved.

Characteristic of CISC –

1. Complex instruction, hence complex instruction decoding.
2. Instructions are larger than one-word size.
3. Instruction may take more than a single clock cycle to get executed.
4. Less number of general-purpose registers as operations get performed in memory itself.
5. Complex Addressing Modes.



SNS COLLEGE OF TECHNOLOGY, COIMBATORE –35
(An Autonomous Institution)



DEPARTMENT OF COMPUTER SCIENCE AND ENGINEERING

6. More Data types.

Example – Suppose we have to add two 8-bit numbers:

- **CISC approach:** There will be a single command or instruction for this like ADD which will perform the task.
- **RISC approach:** Here programmer will write the first load command to load data in registers then it will use a suitable operator and then it will store the result in the desired location.

So, add operation is divided into parts i.e. load, operate, store due to which RISC programs are longer and require more memory to get stored but require fewer transistors due to less complex command.

Difference –

RISC	CISC
Focus on software	Focus on hardware
Uses only Hardwired control unit	Uses both hardwired and microprogrammed control unit
Transistors are used for more registers	Transistors are used for storing complex Instructions
Fixed sized instructions	Variable sized instructions
Can perform only Register to Register Arithmetic operations	Can perform REG to REG or REG to MEM or MEM to MEM
Requires more number of registers	Requires less number of registers
Code size is large	Code size is small
An instruction executed in a single clock cycle	Instruction takes more than one clock cycle
An instruction fit in one word.	Instructions are larger than the size of one word
Simple and limited addressing modes.	Complex and more addressing modes.
RISC is Reduced Instruction Cycle.	CISC is Complex Instruction Cycle.
The number of instructions are less as compared to CISC.	The number of instructions are more as compared to RISC.
It consumes the low power.	It consumes more/high power.
RISC is highly pipelined.	CISC is less pipelined.
RISC required more RAM.	CISC required less RAM.
Here, Addressing modes are less.	