




Nernst equation for electrode potential

Consider the following redox reaction



For such a redox reversible reaction, the free energy change (ΔG) and its equilibrium constant (K) are inter related as

$$\Delta G = -RT \ln K + RT \ln \frac{[Product]}{[Reactant]}$$

$$\Delta G = \Delta G^{\circ} + RT \ln \frac{[Product]}{[Reactant]} \quad \text{..... (1)}$$

where,

ΔG° = Standard free energy change

The above equation (1) is known as *Van't Hoff isotherm*. The decrease in free energy ($-\Delta G$) in the above reaction involves transfer of 'n' number of electrons, then 'n' faraday of electricity will flow. If E is the emf of the cell, then the total electrical energy (nEF) produced in the cell is

$$-\Delta G = nEF \quad (\text{or}) \quad -\Delta G^{\circ} = nE^{\circ}F \quad \text{..... (2)}$$

where, $-\Delta G$ = decrease in free energy change.

(or) $-\Delta G^{\circ}$ = decrease in standard free energy change. Comparing equation 1 and 2, it becomes

$$-nEF = -nE^{\circ}F + RT \ln \frac{[M]}{[M^{n+}]} \quad \text{..... (3)}$$

Dividing the above equation (3) by $-nF$

[the activity of solid metal $[M] = 1$]

$$E = E^{\circ} - \frac{RT}{nF} \ln \frac{1}{[M^{n+}]}$$

$$\text{In general, } E = E^{\circ} - \frac{RT}{nF} \ln \frac{[Product]}{[Reactant]}$$

(or)

$$E = E^{\circ} + \frac{2.303RT}{nF} \log [M^{n+}] \quad \text{-----(4)}$$



When, $R = 8.314 \text{ J/K/mole}$; $F = 96500 \text{ coulombs}$; $T = 298 \text{ K (} 25^\circ\text{C)}$, the above equation becomes

$$E = E^\circ_{\text{red}} + \frac{0.0591}{n} \log[M^{n+}] \quad \text{-----(5)}$$

$$E = E^\circ_{\text{oxi}} - \frac{0.0591}{n} \log C \quad \text{-----(6)}$$

The above equation 5&6 are known as “Nernst equation for single electrode potential”.

Applications of Nernst equations

1. Nernst equation is used to calculate electrode potential of unknown metal.
2. Corrosion tendency of metals can be predicted.
3. It is used to calculate the EMF of a cell.
4. pH of a solution can be calculated by measuring emf.
5. Concentration of solution in galvanic cell can be determined