



SNS COLLEGE OF TECHNOLOGY

An Autonomous Institution

Coimbatore-35



Accredited by NBA – AICTE and Accredited by NAAC – UGC with 'A++' Grade
Approved by AICTE, New Delhi & Affiliated to Anna University, Chennai

DEPARTMENT OF ELECTRONICS & COMMUNICATION ENGINEERING

19ITT204 - MICROCONTROLLER AND EMBEDDED SYSTEMS

II YEAR/ IV SEMESTER

UNIT II PERIPHERAL INTERFACING

TOPIC – 8279 Keyboard and Display Controller



OUTLINE



Keyboard/Display Controller INTEL 8279



Introduction:

- Direct Memory Access (DMA) is a method of allowing data to be moved from one location to another in a computer without intervention from the central processor (CPU).
- It is also a fast way of transferring data within (and sometimes between) computer.
- The DMA I/O technique provides direct access to the memory while the microprocessor is temporarily disabled.
- The DMA controller temporarily borrows the address bus, data bus and control bus from the microprocessor and transfers the data directly from the external devices to a series of memory locations (and vice versa).




Features of 8279

- **Simultaneous keyboard and display operations**
- **Scanned keyboard mode**
- **Scanned sensor mode**
- **8-character keyboard FIFO**
- **1 6-character display**



Pin Diagram





8279 Pin Configuration



4 sections

- **Keyboard section**
- **Display section**
- **Scan section**
- **CPU interface section**





8279 Internal Architecture



Keyboard section

- The keyboard section consists of **8 return** lines **RLO - RL7** that can be used to form the columns of a keyboard matrix.
- It has two additional input : **shift** and **control/strobe**. The keys are automatically debounced.
- The two operating modes of keyboard section are **2-key lockout** and **N-key rollover**.



- In the **2-key lockout** mode, if two keys are pressed simultaneously, only the first key is recognized.
- In the **N-key rollover** mode simultaneous keys are recognized and their codes are stored in FIFO.
- The keyboard section also have an 8 x 8 FIFO (First In First Out) RAM.
- The FIFO can store eight key codes in the scan keyboard mode. The status of the shift key and control key are also stored along with key code. The 8279 generate an interrupt signal (IRQ) when there is an entry in FIFO.



Display section

- The display section has eight output lines divided into two groups **A0-A3** and **B0-B3**.
- The output lines can be used either as a single group of eight lines or as two groups of four lines, in conjunction with the scan lines for a multiplexed display.
- The output lines are connected to the anodes through driver transistor in case of common cathode 7-segment LEDs.



- **The cathodes are connected to scan lines through driver transistors.**
- **The display can be blanked by BD (low) line.**
- **The display section consists of 16 x 8 display RAM. The CPU can read from or write into any location of the display RAM.**



Scan section

- The scan section has a scan counter and four scan lines, **SL0 to SL3**.
- In decoded scan mode, the output of scan lines will be similar to a **2-to-4 decoder**.
- In encoded scan mode, the output of scan lines will be binary count, and so an external decoder should be used to convert the binary count to decoded output.
- The scan lines are common for keyboard and display.



CPU interface section

- The CPU interface section takes care of data transfer between 8279 and the processor.
- This section has eight bidirectional data lines DB0 to DB7 for data transfer between 8279 and CPU.
- It requires two internal address $A = 0$ for selecting **data buffer** and $A = 1$ for selecting **control register** of 8279.



- **The control signals WR (low), RD (low), CS (low) and A0 are used for read/write to 8279.**
- **It has an interrupt request line IRQ, for interrupt driven data transfer with processor.**
- **The 8279 require an internal clock frequency of 100 kHz. This can be obtained by dividing the input clock by an internal prescaler.**



Command Words of 8279

All the command words or status words are written or read with **A0 = 1** and **CS = 0** to or from **8279**.

- a) **Keyboard Display Mode Set** : The format of the command word to select different modes of operation of 8279 is given below with its bit definitions.

D7	D6	D5	D4	D3	D2	D1	D0
0	0	0	D	D	K	K	K

D	D	Display modes
0	0	Eight 8-bit character Left entry
0	1	Sixteen 8-bit character left entry
1	0	Eight 8-bit character Right entry
1	1	Sixteen 8-bit character Right entry



B) Programmable clock :

- The clock for operation of 8279 is obtained by **dividing the external clock input** signal by a programmable constant called prescaler.
- PPPPP** is a 5-bit binary constant.
- The input frequency is divided by a decimal constant ranging **from 2 to 31**, decided by the bits of an internal prescaler, PPPPP.

D7	D6	D5	D4	D3	D2	D1	D0
0	0	1	P	P	P	P	P



c) **Read FIFO / Sensor RAM** : The format of this command is given below. 97

D7	D6	D5	D4	D3	D2	D1	D0
0	1	0	AI	X	A	A	A

AI – Auto Increment Flag

AAA – Address pointer to 8 bit FIFO RAM

X- Don't care

- This word is written to set up 8279 for **reading FIFO/ sensor RAM**.
- In **scanned keyboard mode**, AI and AAA bits are of no use. The 8279 will automatically drive data bus for each subsequent read, in the same sequence, in which the data was entered.
- In sensor matrix mode, the bits AAA select one of the 8 rows of RAM.
- If **AI flag is set**, each successive read will be from the subsequent RAM location.



d) Read Display RAM :

This command enables a programmer to read the display RAM data.

D7	D6	D5	D4	D3	D2	D1	D0
0	1	1	AI	A	A	A	A

- The CPU writes this command word to 8279 to prepare it for display RAM read operation.
- AI is **auto increment flag** and **AAAA**, the 4-bit address points to the **16-byte** display RAM that is to be read.
- If AI=1, the address will be **automatically, incremented** after each read or write to the Display RAM.
- The **same address counter** is used for reading and writing.



d) **Write Display RAM :**

This command enables a programmer to write the display RAM data.

D7	D6	D5	D4	D3	D2	D1	D0
1	0	0	AI	A	A	A	A

AI – Auto increment Flag.

AAAA – 4 bit address for 16-bit display RAM to be written.

e) **Display Write Inhibit/Blanking :**

D7	D6	D5	D4	D3	D2	D1	D0
1	0	1	X	IW	IW	BL	BL

IW - inhibit write flag

BL - blank display bit flags



g) Clear Display RAM :

D7	D6	D5	D4	D3	D2	D1	D0
1	1	0	CD2	CD1	CD0	CF	CA



ENABLES CLEAR DISPLAY
WHEN CD2=1

0X - All zeros (x don't care) AB=00
10 - A3-A0 =2 (0010) and B3-B0=00 (0000)
11 - All ones (AB =FF), i.e. clear RAM

- **CD2 must be 1** for enabling the clear display command.
- If CD2 = 0, the clear display command is invoked by setting **CA(CLEAR ALL) =1** and maintaining CD1, CD0 bits exactly same as above.
- If **CF(CLEAR FIFO RAM STATUS) =1**, FIFO status is cleared and IRQ line is pulled down and the sensor RAM pointer is set to row 0.
- If **CA=1**, this combines the effect of CD and CF bits.



h) **End Interrupt / Error mode Set :**

D7	D6	D5	D4	D3	D2	D1	D0
1	1	1	E	X	X	X	1

E- Error mode
X- don't care

- For the **sensor matrix mode**, this command lowers the IRQ line and enables further writing into the RAM.
- Otherwise, if a change in sensor value is detected, IRQ goes high that inhibits writing in the sensor RAM.
- For **N-Key roll over mode**, if the E bit is programmed to be '1', the 8279 operates in special Error mode



THANK YOU