



SNS COLLEGE OF TECHNOLOGY

(An Autonomous Institution)

COIMBATORE-35

Accredited by NBA-AICTE and Accredited by NAAC – UGC with A+ Grade

Approved by AICTE, New Delhi & Affiliated to Anna University, Chennai



DEPARTMENT OF ELECTRICAL AND ELECTRONICS ENGINEERING

19EET202 / ANALOG ELECTRONICS
II YEAR / III SEMESTER

UNIT-II: MULTIJUNCTION DEVICES

JUNCTION FIELD EFFECT TRANSISTOR




Introduction (FET)

Field-effect transistor (FET) are important devices such as BJTs

- Also used as amplifier and logic switches
- What is the difference between JFET and BJT?




BJT is Current-controlled






FET is Voltage-controlled





Types of Field Effect Transistors (The Classification)





Production.. (Advantages of FET over BJT)

High input impedance ($M\Omega$)
(Linear AC amplifier system)

- Temperature stable than BJT
- Smaller than BJT
- Can be fabricated with fewer processing
- BJT is bipolar – conduction both hole and electron
- FET is unipolar – uses only one type of charge carrier
- Less noise compare to BJT
- Usually use as an Amplifier and logic switch



Disadvantages of FET

Easy to damage compare to BJT



unction field-effect transistor..

There are 2 types of **JFET**


- n-channel JFET
- p-channel JFET

Three Terminal


- Drain – D
- Gate -G
- Source – S



SYMBOLS



n-channel JFET



p-channel JFET




N-channel JFET

N channel JFET

- Major structure is **n-type material (channel)** between embedded **p-type material** to form 2 p-n junction.
- In the normal operation of an n-channel device, the **Drain (D)** is positive with respect to the **Source (S)**. Current flows into the Drain (D), through the channel, and out of the Source (S)
- Because the resistance of the channel depends on the **gate-to-source voltage (V_{GS})**, the **drain current (I_D)** is controlled by that voltage



N-channel JFET..






P-channel JFET

P channel JFET:

- Major structure is **p-type material (channel)** between embedded **n-type material** to form 2 p-n junction.
- Current flow : from **Source (S)** to **Drain (D)**
- **Holes** injected to **Source (S)** through **n-type channel** and flowed to **Drain (D)**.




P-channel JFET..









Water analogy for the JFET control mechanism





-  P-type (gate)
-  N-type (channel)
-  Depletion zone

© J. C. G. Lesurf Univ. St. Andrews





JFET Operating Characteristics

There are three basic operating conditions for a JFET:

- $V_{GS} = 0$, V_{DS} increasing to some positive value
- $V_{GS} < 0$, V_{DS} at some positive value
- Voltage-controlled resistor




JFET Characteristic for $V_{GS} = 0$ V and $0 < V_{DS} < |V_p|$

- To start, suppose $V_{GS} = 0$
- Then, when V_{DS} is increased, I_D increases. Therefore, I_D is proportional to V_{DS} for small values of V_{DS}
- For larger value of V_{DS} , as V_{DS} increases, the depletion layer become wider, causing the resistance of channel increases.
- After the pinch-off voltage (V_p) is reached, I_D becomes nearly constant (called as $I_{D,max}$)
 I_{DSS} -Drain to Source current with Gate Short




JFET for V_{GS}

$= 0 \text{ V}$ and $0 < V_{DS} < |V_p|$



Channel becomes narrower as V_{DS} is increased


Pinch-off ($V_{GS} = 0 \text{ V}, V_{DS} = V_P$).





I_D versus V_{DS}

for $V_{GS} = 0$ V and $0 < V_{DS} < |V_p|$



JFET Characteristic Curve



$V_{GS} < 0$, V_{DS} at some positive value

JFET Characteristic Curve..

- For negative values of V_{GS} , the gate-to-channel junction is reverse biased even with $V_{DS} = 0$
- Thus, the initial channel resistance of channel is higher.
- The resistance value is under the control of V_{GS}
- If $V_{GS} =$ pinch-off voltage (V_P)
The device is in **cutoff** ($V_{GS} = V_{GS(off)} = V_P$)
- The region where I_D constant – The **saturation/pinch-off region**
- The region where I_D depends on V_{DS} is called the **linear/ohmic region**




$V_{GS} < 0$, V_{DS} at some positive value

JFET Operating Characteristics

As V_{GS} becomes more negative:

- The JFET experiences pinch-off at a lower voltage (V_P).
- I_D decreases ($I_D < I_{DSS}$) even though V_{DS} is increased.
- Eventually I_D reaches 0 A. V_{GS} at this point is called V_P or $V_{GS(off)}$.




Also note that at high levels of V_{DS} the JFET reaches a breakdown situation. I_D increases uncontrollably if $V_{DS} > V_{DSmax}$.

p-Channel JFET characteristics with

$I_{DSS} = 6 \text{ mA}$ and

$V_P = +6 \text{ V}$.





Transfer Characteristics


The input-output transfer characteristic of the JFET is not as straight forward as it is for the BJT. In BJT:

$$I_C = \beta I_B$$

which β is defined as the relationship between I_B (input current) and I_C (output current).



RECAP....



...THANK YOU