


Process Concept

- An operating system executes a variety of programs:
 - Batch system – jobs
 - Time-shared systems – user programs or tasks
- The terms *job* and *process* almost interchangeably
- Process – a program in execution; process execution must progress in sequential fashion
- A process includes:
 - program counter
 - stack
 - data section

The Process

- The program code, also called **text section**
- Current activity including **program counter**, processor registers
- **Stack** containing temporary data
 - Function parameters, return addresses, local variables
- **Data section** containing global variables
- **Heap** containing memory dynamically allocated during run time
- Program is passive entity, process is active
 - Program becomes process when executable file loaded into memory
- Execution of program started via GUI mouse clicks, command line entry of its name, etc
- One program can be several processes
 - Consider multiple users executing the same program

Process in Memory



Process State

- As a process executes, it changes state

A process may be in one of the following states:

New. The process is being created.


- Running. Instructions are being executed.

- Waiting. The process is waiting for some event to occur (such as an I/O completion or reception of a signal).

- Ready. The process is waiting to be assigned to a processor

- Terminated. The process has finished execution

Process State



Process Control Block

- Each process is represented in the operating system by a process control block (PCB)—also called a task control block.
- **Process state.** The state may be new, ready, running, waiting, halted, and so on.
- **Program counter.** The counter indicates the address of the next instruction to be executed for this process.

CPU registers. They include accumulators, index registers, stack pointers, and general-purpose registers, plus any condition-code information.


Process Control Block

- **CPU-scheduling information.** This information includes a process priority, pointers to scheduling queues, and any other scheduling parameters.
- **Memory-management information.** This information may include such items as the value of the base and limit registers and the page tables, or the segment tables, depending on the memory system used by the operating system
- **Accounting information.** This information includes the amount of CPU and real time used, time limits, account numbers, job or process numbers, and so on.
- **I/O status information.** This information includes the list of I/O devices allocated to the process, a list of open files, and so on

Process Control Block (PCB)




CPU Switch From Process to Process



Process Scheduling

- Maximize CPU use, quickly switch processes onto CPU for time sharing
- **Process scheduler** selects among available processes for next execution on CPU
- Maintains **scheduling queues** of processes
 - **Job queue** – set of all processes in the system
 - **Ready queue** – set of all processes residing in main memory, ready and waiting to execute
 - **Device queues** – set of processes waiting for an I/O device

Representation of Process Scheduling




Schedulers

- **Long-term scheduler** (or job scheduler) – selects which processes should be brought into the ready queue
- **Short-term scheduler** (or CPU scheduler) – selects which process should be executed next and allocates CPU
 - Sometimes the only scheduler in a system

Schedulers (Cont.)

- Processes can be described as either:
 - **I/O-bound process** – spends more time doing I/O than computations, many short CPU bursts
 - **CPU-bound process** – spends more time doing computations; few very long CPU bursts

Medium Term Scheduling



Context Switch

- When CPU switches to another process, the system must save the state of the old process and load the saved state for the new process via a **context switch**.
- **Context** of a process represented in the PCB
- Context-switch time is overhead; the system does no useful work while switching
 - The more complex the OS and the PCB -> longer the context switch
- Time dependent on hardware support